

POWER GRIP EXTENDED BATTERY FOR SONY FH, JVC VF800, PANASONIC VBG



For Panasonic
VBG-260



For SONY
NP-FH70



For JVC
BN-VF815



Insert Original Battery on the
Power Grip (Extended Battery)



Connect original battery to Power
Grip as a combined unit
(For initial use, please leave the
combined unit for at least half an
hour before charging.)



Insert combined unit
onto camcorder.